

Instructions (268 & 26801)

THIS UNIT FITS ONLY:	318i	05/82 - 07/85	325	10/84 - 01/86
	325e	10/83 - 01/86	325eS	11/85 - 01/86

Prior to installation, verify this is the correct part for your application.

26801 units are battery less disregard instructions concerning batteries.
268 units have batteries.

- 1. Remove light bar from old unit and place on new unit.**
- 2. Make sure battery jumper is placed to the on position.**
- 3. For correct operation, unit must be reset after installation.**

GENERAL TROUBLESHOOTING NOTES

NEW UNIT PROBLEMS

Symptom	Test/Suspect Problem	Solution
Inspection light will not reset.	Batteries are not turned on.	Move jumper to on position.
Light board has missing lights.	Visual inspection for cracked or corroded solders.	Replace light board.
No green lights.	Light bar missing.	Remove light bar from old unit and install in ProgRama unit.
Inspection light will not reset.	Check pin #7 for 5 volts at the diagnostic connector in the engine compartment.	Replace conductor plate.
Temperature not working.	Conductor plate, visual inspection for cracked or corroded solders.	Replace conductor plate.
Instrument cluster is performing incorrectly.	Conductor plate, visual inspection for cracked or corroded solders.	Replace conductor plate.